

OPERATING INSTRUCTIONS

NOTE: THE POWER PROBE TEK BUTANE TORCH DOES NOT CONTAIN ANY BUTANE GAS WHEN PURCHASED. FOLLOW THE GAS FILLING INSTRUCTIONS TO MAKE IT OPERATIONAL.

GAS FILLING & REFILLING

1. Make sure the torch is turned off before filling.
2. Shake the gas container a few times to warm the fuel up. Insert the container nozzle vertically down into the filling valve.
3. When the gas starts to overflow, remove container nozzle from filling valve to stop the filling action. Complete refilling takes approximately 40 to 50 seconds.
4. Allow a few minutes for the gas to stabilize.

**If gas still escapes from the filling valve after the refilling is completed, insert the container nozzle into the filling valve again. Move the nozzle slightly up and down, then remove from the valve until the leakage problem has been resolved.*

IGNITION

1. Turn the **SAFETY LOCK** to the upright position.
2. Make the notch on the **AIR CONTROL SLEEVE** coincide with the hole on the body.
3. Turn the **GAS CONTROL KNOB** slowly to the left. You will hear the gas escaping.
4. Press the **IGNITION BUTTON**. The Torch will ignite instantly.

SHUT-OFF

1. Turn the **GAS CONTROL KNOB** to the right [clockwise] to turn off the flame.

FLAME LENGTH ADJUSTMENT

1. Turn the **GAS CONTROL KNOB** to the left to increase the flame and to the right to decrease and/or extinguish the flame.

THERMAL POWER CONTROL

1. Turn the **AIR CONTROL SLEEVE** either to the left or right to obtain the required temperature.

**The highest temperature attainable is approximately 1,300°C.*

CAUTION

1. Do not touch the flame guard when hot.
2. Keep out of reach of children.
3. Butane gas is highly flammable. Please handle with care.
4. Always point the torch away from eyes and body when igniting and operating.
5. Make sure the **GAS CONTROL KNOB** is firmly closed, the flame is completely extinguished, and the **SAFETY LOCK** is engaged and locked after use.
6. Do not drop, puncture, incinerate, expose to direct sunlight, or store in temperatures exceeding 50°C.